

モバイルモーションキャプチャー Mobile Motion Capture

リファレンスガイド Reference Guide

リファレンスガイド Reference Guide




QRコード

QM-SS1

日本語
本機のマニュアルについて
 <p>本機の詳しい使いかたは、ヘルプガイド (Web取扱説明書) をご覧ください。</p>
ヘルプガイド (Web取扱説明書) https://rd1.sony.net/help/mobile/qm-ss1/ja/

安全のために

- ご使用前に、この「安全のために」をよくお読みの上、正しくお使いください。また、お読みになった後は大切に保管してください。
- ここに示した注意事項は、お使いになる人や、他の人への危害、財産への損害を未然に防ぐための内容を記載していますので、必ずお守りください。
- 次の表示の区分は、表示内容を守らず、誤った使用をした場合に生じる危害や損害の程度を説明しています。





	この表示は、取り扱いを誤った場合、「死亡または重傷 ^{※1} を負う危険が切迫して生じることが想定される」内容です。
	この表示は、取り扱いを誤った場合、「死亡または重傷 ^{※1} を負う可能性が想定される」内容です。
	この表示は、取り扱いを誤った場合、「軽傷 ^{※2} を負う可能性が想定される場合および物的損害 ^{※3} の発生が想定される」内容です。












※1 重傷：失明・けが・やけど(高温・低温)・感電・骨折・中毒などで後遺症が残るもの、および治療に入院や長期の通院を要するものを指します。


※2 軽傷：治療に入院や長期の通院を要さない、けが・やけど(高温・低温)・感電などを指します。

※3 物的損害：家屋・家財および家畜・ペットなどにかかわる拡大損害を指します。

禁止・強制の絵表示の説明

	禁止(してはいけないこと)を示す記号です。		指示に基づく行為の強制(必ず実行していただくこと)を示す記号です。
	分解してはいけないことを示す記号です。		
	水がかかるところで使用したり、水にぬらしたりしてはいけないことを示す記号です。		


高温になる場所や熱のこもりやすい場所(火のそば、暖房器具のそば、こたつや布団の中、直射日光の当たる場所、炎天下の車内など)で使用、充電、保管、放置しないでください。 <p>火災、やけど、けが、感電などの原因となります。</p>

電子レンジ、IH調理器などの加熱調理器、圧力釜などの高圧容器に入れたり、近くに置いたりしないでください。 <p>火災、やけど、けが、感電などの原因となります。</p>

砂や土、泥をかいたり、直に置いたりしないでください。 <p>また、砂などが付着した手で触れないでください。</p> <p>火災、やけど、けが、感電などの原因となります。</p>

水などの液体(飲料水、汗、海水、ペットの尿など)が濡れた状態では、充電しないでください。 <p>また、風呂場や加湿器のそばなどの水に触れる場所では、充電しないでください。</p> <p>火災、やけど、けが、感電などの原因となります。</p>

センサーに強い圧力を加えたり、折損させたりしないでください。 <p>特に衣類のポケットに入れて持ち運ぶ場合は、ぶつかけたり、物に挟んだりしないでください。</p> <p>電池の破損により、火災、やけど、けがなどの原因となります。</p>

分解、改造をしないでください。 <p>火災、やけど、けが、感電などの原因となります。</p>

センサーの内蔵電池を取り外そうとしないでください。 <p>火災、やけど、けがなどの原因となります。</p>

充電端子に水などの液体(飲料水、汗、海水、ペットの尿など)を入れないでください。 <p>火災、やけど、けが、感電などの原因となります。</p>

ソニー製のACアダプターおよびケーブルを使用してください。 <p>指定以外のものを使用すると、火災、やけど、けが、感電などの原因となります。</p>

火の中に投入したり、熱を加えたりしないでください。 <p>火災、やけど、けがなどの原因となります。</p>


 **湿気やほこりの多い場所や高温になる場所での使用、保管はしないでください。**

火災、やけど、感電などの原因となります。

| |
| **子供が使用する場合は、保護者が取り扱いの方法を教え、誤った使いかたをさせないでください。** 誤飲、けが、感電などの原因となります。 |
| |
| **乳幼児やペットが届く場所に置かないでください。** 誤飲、けが、感電などの原因となります。 |
| |
| **センサーを継続してご使用になる場合や充電中は温度が高くなることがありますのでご注意ください。** また、衣類のポケットに入れたり、眠ってしまうなどして、意図せず継続して触れることがないようにご注意ください。 モーションキャプチャー中や充電中は、センサーや充電ケースの温度が高くなることがあります。温度の高い部分に直接継続して触れるとお客様の体質や体調によっては肌の赤みやかゆみ、かぶれ、低温やけどなどの原因となりますので、衣類のポケットに入れたまま就寝しないでください。 |
| |
| **センサー、クリップ、バンドのアタッチメントおよび充電ケースに磁気を発生する部品を使用しているため、金属片(カッターの刃やホチキスの針など)が付着していないことを確認してください。** 付着物により、けがなどの原因となります。 |
| |
| **内蔵電池内部の物質が漏れた場合は、顔や手などの皮膚や衣類などにつけないでください。** 目や皮膚への傷害などを起こす原因となります。内部の物質が目や口などに入った場合や、皮膚や衣類に付着した場合は、すぐにきれいな水で洗い流してください。また、目や口などに入った場合は、洗浄後直ちに医師の診療を受けてください。 |
| |
| **バンドが汚れた場合には、拭き取るなど清潔にしてください。** 定期的なお手入れをおすすめします。センサーおよびバンドの使用により、皮膚に異状が生じた場合は、直ちに使用をやめ、医師の診療を受けてください。 お客様の体質や体調によっては、かゆみ、かぶれ、湿疹などが生じることがあります。 本書の材質一覧もご確認ください。 |
| |
| **医療機器に近づけないでください。** センサー、クリップ、バンドのアタッチメントおよび充電ケースは磁石を使用しているため、ペースメーカー、水頭症治療用圧可変式シャントなどの医療機器に影響を与えるおそれがあります。本機をこれらの医療機器をご使用の方に近づけないでください。これらの医療機器を使用されている場合、本機のご使用前に担当医師にご相談ください。 |
| |
| **一般のごゴミと一緒に捨てないでください。** 火災、やけど、けがなどの原因となります。また、環境破壊の原因となります。不要となった本機は、相談窓口にお持ちいただくか、回収を行っている市区町村の指示に従ってください。 |
| |
| **子供や監督を必要とする方などの手の届くところに置かないでください。** センサー、クリップ、バンドのアタッチメントおよび充電ケースは磁石を使用しています。磁石を飲み込むと、窒息の危険性や腸などを傷つけ深刻な症状を引き起こすおそれがあります。磁石を飲み込んだ場合は直ちに医師にご相談ください。 |
| |
| **センサー、クリップ、バンドのアタッチメントおよび充電ケースを磁気カードに近づけないでください。** センサー、クリップ、バンドのアタッチメントおよび充電ケースは磁石を使用しています。磁気を利用したカード類を近づけると、カードの磁気に変化して使えなくなることがあります。 |
| |
| **バンドを皮膚に強く当てて使用しないでください。** きつく締め過ぎないでください。 不快感、皮膚炎などの原因になります。 |
| |
| **センサーは、充電ケースに正しい向きでセットしてください。** 無理な力を加えたり、充電ケースとセンサーの充電端子を逆向きに接触したりすると、けがや故障などの原因となります。 |
| |

警告

落下させる、踏みつける、投げつけるなど強い力や衝撃、振動を与えないでください。

火災、やけど、けが、感電などの原因となります。

| |
| **充電端子に導電性異物(金属片、鉛筆の芯など)を接触させたり、ほこりが内部に入ったりしないようにしてください。** 火災、やけど、けが、感電などの原因となります。 |
| |
| **所定の充電時間を超過しても充電が完了しない場合は、充電を中止してください。** 過充電などにより、火災、やけど、けがなどの原因となります。 |
| |
| **可燃性ガスが発生する可能性のある場所や粉塵が発生する場所に立ち入る場合は、必ず事前に本機の電源を切り、充電をしている場合は中止してください。** 可燃性ガスなどへの引火により爆発や火災などの原因となります。 |
| |
| **ガソリンスタンド構内などでの使用については、各施設の指示に従ってください。** ガソリンスタンド構内などでは充電をしないでください。また、ガソリンスタンド構内などでご使用になる際は落下などに注意し、特に給油中は使用しないでください。可燃性ガスなどへの引火により爆発や火災などの原因となります。 |
| |
| **使用中、充電中、保管中に、異臭、異音、発煙、発熱、変色、変形などの異常がみられた場合は安全に注意し、充電ケースからケーブルを抜いてください。** 火災、やけど、けが、感電などの原因となります。 |
| |
| **航空機内での使用については各航空会社の指示に従ってください。** 電波により航空機の電子機器に悪影響を及ぼす原因となります。なお、航空機内での使用において禁止行為をした場合、法令により罰せられることがあります。 |
| |
| **病院での使用については、各医療機関の指示に従ってください。** 使用を禁止されている場所では、本機の電源を切ってください。 電波により電子機器や医用電気機器に悪影響を及ぼす原因となります。 |
| |
| **医用電気機器などを装着している場合は、医用電気機器メーカーもしくは販売業者に、電波による影響についてご確認の上ご使用ください。** 電波により医用電気機器などに悪影響を及ぼす原因となります。 |
| |
| **高精度な制御や微弱な信号を取り扱う電子機器の近くでは、本機の電源を切ってください。** 電波により電子機器が誤動作するなどの悪影響を及ぼす原因となります。 ※ご注意いただきたい電子機器の例 補聴器、植込み型心臓ペースメーカーおよび植込み型除細動器、その他の医用電気機器、その他の自動制御機器など。 植込み型心臓ペースメーカーおよび植込み型除細動器、その他の医用電気機器をご使用になる方は、各医用電気機器メーカーもしくは販売業者に電波による影響についてご確認ください。 |
| |
| **内蔵電池が漏液したり、異臭がしたりするときは、直ちに使用をやめて火気から遠ざけてください。** 漏液した液体に引火し、発火、破裂などの原因となります。 |
| |
| **ペットなどがセンサーに噛みつかないようにご注意ください。** 内蔵電池の発火、破裂、発熱、漏液により、火災、やけど、けがなどの原因となります。 |
| |
| **充電ケースにケーブルを接続した状態で、接続部に無理な力を加えないでください。** 火災、やけど、けが、感電などの原因となります。 |
| |
| **充電ケースにケーブルを抜き差しする場合は、コードを引っ張るなど無理な力を加えず、接続する端子に対してまっすぐ抜き差ししてください。** 正しく抜き差ししないと、火災、やけど、けが、感電などの原因となります。 |
| |
| **端子や充電ピンが曲がるなど変形した場合は、直ちに使用をやめてください。** また、変形を元に戻しての使用もやめてください。 USB端子や充電端子、充電ピンのショートにより、火災、やけど、けが、感電などの原因となります。 |
| |


注意

高温になる場所や熱のこもりやすい場所(火のそば、暖房器具のそば、こたつや布団の中、直射日光の当たる場所、炎天下の車内など)で使用、充電、保管、放置しないでください。

火災、やけど、けが、感電などの原因となります。

| |
| **電子レンジ、IH調理器などの加熱調理器、圧力釜などの高圧容器に入れたり、近くに置いたりしないでください。** 火災、やけど、けが、感電などの原因となります。 |
| |
| **砂や土、泥をかいたり、直に置いたりしないでください。** また、砂などが付着した手で触れないでください。 火災、やけど、けが、感電などの原因となります。 |
| |
| **水などの液体(飲料水、汗、海水、ペットの尿など)が濡れた状態では、充電しないでください。** また、風呂場や加湿器のそばなどの水に触れる場所では、充電しないでください。 火災、やけど、けが、感電などの原因となります。 |
| |
| **電子レンジ、IH調理器などの加熱調理器、圧力釜などの高圧容器に入れたり、近くに置いたりしないでください。** 火災、やけど、けが、感電などの原因となります。 |
| |
| **砂や土、泥をかいたり、直に置いたりしないでください。** また、砂などが付着した手で触れないでください。 火災、やけど、けが、感電などの原因となります。 |
| |
| **水などの液体(飲料水、汗、海水、ペットの尿など)が濡れた状態では、充電しないでください。** また、風呂場や加湿器のそばなどの水に触れる場所では、充電しないでください。 火災、やけど、けが、感電などの原因となります。 |
| |
| **電子レンジ、IH調理器などの加熱調理器、圧力釜などの高圧容器に入れたり、近くに置いたりしないでください。** 火災、やけど、けが、感電などの原因となります。 |
| |
| **砂や土、泥をかいたり、直に置いたりしないでください。** また、砂などが付着した手で触れないでください。 火災、やけど、けが、感電などの原因となります。 |
| |
| **水などの液体(飲料水、汗、海水、ペットの尿など)が濡れた状態では、充電しないでください。** また、風呂場や加湿器のそばなどの水に触れる場所では、充電しないでください。 火災、やけど、けが、感電などの原因となります。 |
| |
| **電子レンジ、IH調理器などの加熱調理器、圧力釜などの高圧容器に入れたり、近くに置いたりしないでください。** 火災、やけど、けが、感電などの原因となります。 |
| |
| **砂や土、泥をかいたり、直に置いたりしないでください。** また、砂などが付着した手で触れないでください。 火災、やけど、けが、感電などの原因となります。 |
| |
| **水などの液体(飲料水、汗、海水、ペットの尿など)が濡れた状態では、充電しないでください。** また、風呂場や加湿器のそばなどの水に触れる場所では、充電しないでください。 火災、やけど、けが、感電などの原因となります。 |
| |
| **電子レンジ、IH調理器などの加熱調理器、圧力釜などの高圧容器に入れたり、近くに置いたりしないでください。** 火災、やけど、けが、感電などの原因となります。 |
| |
| **砂や土、泥をかいたり、直に置いたりしないでください。** また、砂などが付着した手で触れないでください。 火災、やけど、けが、感電などの原因となります。 |
| |
| **水などの液体(飲料水、汗、海水、ペットの尿など)が濡れた状態では、充電しないでください。** また、風呂場や加湿器のそばなどの水に触れる場所では、充電しないでください。 火災、やけど、けが、感電などの原因となります。 |
| |
| **電子レンジ、IH調理器などの加熱調理器、圧力釜などの高圧容器に入れたり、近くに置いたりしないでください。** 火災、やけど、けが、感電などの原因となります。 |
| |

充電式電池について




機器に内蔵されている充電式電池はリサイクルできます。この充電式電池の取り外しはお客様自身では行わず、「ソニーの相談窓口」にご相談ください。(「ソニーの相談窓口」の連絡先については、本取扱説明書をご覧ください。)

電波法の認証表示

本機に内蔵の通信モジュールは電波法の工事設計認証を受けております。

認証取得のモジュール名：QM-SS1S

：003-220334

Bluetooth®機器について

周波数について

本機のBluetooth機能は2.4GHz帯の2.400GHzから2.4835GHzの周波数を使用していますが、他の無線機器も同じ周波数を使っていることがあります。他の無線機器との電波干渉を防止するために、下記事項に注意してください。

| **Bluetooth機能の使用上の注意事項** この周波数帯では、電子レンジ等の産業・科学・医療用機器のほか、他の同種無線局、工場の製造ライン等で使用される免許を要する移動体識別用構内無線局、免許を要しない特定の小電力無線局、アマチュア無線局等(以下「他の無線局」と略す)が運用されています。 - 本機を使用する前に、近くで「他の無線局」が運用されていないことを確認してください。 - 万一、本機と「他の無線局」との間に電波干渉が発生した場合には、速やかに本機の使用場所を変えるか、または機器の運用を中止(電波の発射を停止)してください。 - 不明な点その他お困りのことが起きたときは、相談窓口にお問い合わせください。相談窓口については、本取扱説明書をご覧ください。 |
| |
| この無線機器は2.4 GHz帯を使用します。変調方式としてその他の方式を採用し、干渉距離は10m以下です。 |

2.4XX1

この無線機器は2.4 GHz帯を使用します。変調方式としてその他の方式を採用し、干渉距離は10m以下です。

その他のお知らせ

取扱説明書では、第三者が提供するサービスやアプリについて言及する場合があります。上記サービスやアプリを使用するには提供元への登録やライセンス契約が別途必要になる場合があります。第三者のWebサイトでアクセスしたアプリについては、当該Webサイトの利用規約と適用されるプライバシーポリシーを予めご確認ください。当社は、第三者のWebサイトやサービスアプリの利用可能性またはパフォーマンスについて保証はいたしません。

Bluetooth®の登録商標について

- Bluetooth®のワードマークおよびロゴは、Bluetooth SIG, Inc.が所有する登録商標であり、ソニー株式会社はこれらのマークをライセンスに基づいて使用しています。その他の商標および商号は、それぞれの所有者に帰属します。
- USB Type-C®はUSB Implementers Forumの商標です。
- その他、本書で登場するシステム名、製品名は、一般に各開発メーカーの登録商標あるいは商標です。なお、本文中では™、®マークは明記していません。

保証書とアフターサービス

保証書

- この製品には保証書が添付されていますので、お買い上げの際、お受け取りください。
- 所定事項の記入および記載内容をお確かめのうえ、大切に保管してください。
- 保証期間は、お買い上げ日より1年間です。

アフターサービス
調子が悪いときはまずチェックを
この説明書とサポートサイトをご覧になってお調べください。
https://www.sony.jp/support/

それでも具合の悪いときは
ソニーの相談窓口にご相談ください。

保証期間中の修理は

保証書の記載内容に基づいて修理させていただきます。詳しくは保証書をご覧ください。

保証期間経過後の修理は

修理によって機能が維持できる場合は、ご要望により有料修理させていただきます。

部品の保有期間について


当社では本機の補修用性能部品(製品の機能を維持するために必要な部品)を、製造打ち切り後最低3年間保有しています。ただし、故障の状況その他の事情により、修理に代えて製品交換をする場合がありますのでご了承ください。保有期間が経過したあとも、故障箇所によっては修理可能な場合がありますので、お買い上げ店か、ソニーの相談窓口にご相談ください。

ご相談になるときは次のことをお知らせください。

型名：QM-SS1

- 故障の状態：できるだけ詳しく
- お買い上げ年月日

●**各種お問い合わせ(LINEやメールなど)**
詳しくは以下のホームページをご覧ください。
https://www.sony.jp/support/inquiry.html


【修理相談窓口】
フリーダイヤル:0120-222-330
携帯電話—部のIP電話:050-3754-9599
FAX:0120-333-389

ソニー株式会社 〒108-0075 東京都港区港南1-7-1

製品のサポート登録(製品登録)のおすすめ
ソニーは製品をご購入いただいたお客様のサポートの充実を図るため、製品のサポート登録をおすすめしております。詳しくはウェブ上の案内をご覧ください。
https://sony.jp/reg/mmc/



English

About the manual for this product



For details, refer to the "Help Guide" (Web manual).

"Help Guide" (Web manual)

<https://rd1.sony.net/help/mobile/qm-ss1/en/>

Note! Read this information before using your device.

Taking care of and using your device

Danger

- Do not use, charge, store or leave the device in an area with high temperature or susceptible to heat accumulation (e.g. near a fire or heating appliances, under a blanket, in direct sunlight or a car in the hot sun). This may result in a fire, burns, injury, or electric shock.
- Do not place the device inside or near microwave ovens, cooking appliances such as IH cooking heaters, or high pressure containers such as pressure cookers. This may result in a fire, burns, injury, or electric shock.
- Do not splash sand, soil or mud, or directly place the device on surfaces. Do not touch the device with sandy hands. This may result in a fire, burns, injury, or electric shock.
- Do not charge when the device is wet with liquids such as water (e.g. drinking water, sweat, seawater, urine of pet animals). Also, do not charge in an area exposed to water such as in a bathroom or near a humidifier. This may result in a fire, burns, injury, or electric shock.
- Do not apply strong pressure to the sensor or break the sensor. Particularly, when carrying the device in your pocket, do not let it come in contact against something or be caught between objects. This may damage the battery and result in a fire, burns, or injury.
- Do not disassemble or modify the device. This may result in a fire, burns, injury, or electric shock.
- Do not remove the internal battery from the sensor. This may result in a fire, burns, or injury.
- Do not allow liquids such as water (e.g. drinking water, sweat, seawater, urine of pet animals) to enter the charging port. This may result in a fire, burns, injury, or electric shock.
- Use Sony-branded AC adapters and cables. Using adapters and cables other than the specified ones may result in a fire, burns, injury, or electric shock.
- Do not place the device in a fire or apply heat to it. This may result in a fire, burns, or injury.
- Do not pierce the device with a sharp object (such as a nail), hit it with a hard object (such as a hammer), or apply excessive force to it such as by stepping on it. This may result in a fire, burns, or injury.

Warning

- Do not apply strong force, impact, or vibration to the device by letting it fall, stepping on it, or throwing it. This may result in a fire, burns, injury, or electric shock.
- Do not allow conductive foreign material (metallic fragment, pencil lead, etc.) to come in contact with the charging port or allow dust to enter inside. This may result in a fire, burns, injury, or electric shock.
- Stop charging if it does not complete even when the specified charging time has elapsed. Otherwise, a fire, burns, or injury may result due to overcharge, etc.
- When entering locations where flammable gases and dust may occur, be sure to switch off the power of the device and stop charging beforehand. Otherwise, it may result in an explosion, fire, etc. due to flammable gas igniting.
- When using the device within locations such as gas stations, follow the instructions of each facility. Do not charge the device within locations such as gas stations. Also, if using the device in locations such as gas stations, be careful not to drop it. Be sure not to use the device while refueling. Otherwise, it may result in an explosion, fire, etc. due to flammable gas igniting.
- If any abnormalities such as abnormal odors, abnormal noises, smoke generation, heat generation, discoloration, and deformation are detected during use, charging, and storage, pay attention to safety and remove the cable from the charging case. This may result in a fire, burns, injury, or electric shock.
- When using the device on airplanes, follow the instructions of each airline company. The radio waves may affect on-board electronic equipment. Prohibited use of devices on airplanes may be punished by law.
- For use in hospitals, follow the instructions of each medical facility. Power off the device in a place where its use is prohibited. The radio waves may affect electronic equipment and electronic medical equipment.
- If you are wearing electronic medical equipment, check with the manufacturer or vendor how the radio waves affect them. The radio waves may affect electronic medical equipment.
- Power off the device near electronic equipment that use high precision control or weak signals. The radio waves may affect electronic equipment, resulting in malfunction. *Examples of electronic equipment that you should be careful of: Hearing aids, implantable cardiac pacemaker, implantable cardioverter defibrillator, other electronic medical equipment, and other automatic control equipment. For users of implantable cardiac pacemakers, implantable cardioverter defibrillators, or other electronic medical equipment, check with the manufacturer or vendor how the radio waves affect them.
- If the internal battery leaks or has abnormal odor, stop using immediately and keep away from fire. The leaked liquid may catch fire resulting in ignition, explosion, etc.
- Be careful not to allow your pets to bite the sensor. This may result in a fire, burns, or injury due to ignition, explosion, heat generation, or leakage of the internal battery.
- Do not apply excessive force to the connection part while the cable is connected to the charging case. This may result in a fire, burns, injury, or electric shock.
- When removing or inserting cables from or to the charging case, do not apply excessive force such as by pulling on the cord, but remove or insert the cable straight out of or into the port. Failing to correctly remove or insert the cables may result in a fire, burns, injury, or electric shock.
- If the port or charging pin is bent or deformed, immediately stop using the device. Also, refrain from using it after restoring the deformation. This may result in a fire, burns, injury, or electric shock due to a short circuit of the USB port, charging port, or charging pin.

Note

- Do not use the device while damaged. This may result in a fire, burns, or injury.
- Do not use or store the device in locations with high humidity or dust or in locations that reach high temperatures. This may result in a fire, burns, or electric shock.
- If the device is to be used by children, their guardians must teach them how to use it correctly, and must prevent them from using it incorrectly. Otherwise, it may result in accidental ingestion, injury, or electric shock.
- Do not place the device in a location within the reach of infants and pets. Otherwise, it may result in accidental ingestion, injury, or electric shock.
- Note that the temperature may rise when you use the sensors continuously or while charging. Also, be careful not to unintentionally touch the device continuously such as by placing the device in your pocket or falling asleep. During motion capture or while charging, the temperature of the sensors or charging case may rise. Since continued direct contact of high temperature parts may cause redness of the skin, itching, rashes, and low-temperature burns depending on the customer's physical constitution or condition, do not fall asleep while the device is in your pocket.
- Since the sensors, clip, and the sockets on straps and charging case have parts that cause magnetic induction, check that there are no metallic fragments (cutter blades, staples, etc.) attached. Attached substances may result in injury.
- When the substance leaks out from the internal battery, do not let it come into contact with the skin of your face or hands, or clothes. This may result in eye or skin injuries. If the inner substance comes into contact with your eyes, mouth, skin or clothes, immediately rinse the substance with clean water. Consult a doctor immediately after rinsing if the inner substance contacts your eyes or mouth.
- When the straps are soiled, wipe them off to clean them. You are recommended to clean them on a regular basis. If skin abnormalities occur through use of the sensors or straps, immediately stop using the device, and consult with a doctor. Itching, rashes, eczema, etc. may result based on the constitution and physical condition of the customer.
- The sensors, clip, and the sockets on straps and charging case have magnet(s). Swallowing magnet(s) could cause serious harm, such as choking hazard or intestinal injuries. If magnets (or a magnet) were swallowed, consult a doctor immediately. Keep this product away from children or other supervised individuals to prevent accidental ingestion.
- Do not dispose of the device together with usual trash. This may result in a fire, burns, or injury. Also, it may result in environmental destruction. Bring the unnecessary device to a consultation service counter or follow the instructions of your local municipality that has a recycling program.
- The sensors, clip, and the sockets on straps and charging case have magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.
- Keep the sensors, clip, and the sockets on straps and charging case away from magnetic cards. The sensors, clip, and the sockets of straps and charging case use magnets. If you bring magnetic cards close to the device, the magnetism may change, and the cards may become unavailable.
- Do not press the strap forcibly on your skin when using. Do not fasten it too tightly. This may result in discomfort, dermatitis, etc.
- Set the sensors into the charging case in the right orientation. Applying excessive force or letting the charging terminals on the charging case come into contact with the sensors in the reverse orientation may result in injury, malfunction, etc.

Notes on use

- The AI-based estimation technology is used for the motion capture function of the device. Accuracy of estimation may vary by the usage condition or user's physical constitution.
- Perform the motion capture in a wide place, taking care not to hit people or objects. Be careful not to hurt your body. Stop using the device if you feel something unusual. Otherwise, it may result in bodily injury, accident, or malfunction.
- The body height that the device can recognize body movement correctly is between 140 cm (4 feet and 8 inches) and 190 cm (6 feet and 2 inches).
- The motion capture function may not work correctly depending on the communication environment for connecting the device to a smartphone or other surrounding conditions.
- Be careful not to pinch your finger with the clip. It may cause bodily injury.
- Do not allow medicament such as insect repellent spray, sunscreen, or body cream to adhere to the device. This may deform or discolor the device. When such medicament is adhered, wipe it off.
- Do not splash water on the charging case. The charging case is not waterproof. Avoid using in a humid place such as in a bathroom, or exposing to rain drops. Note that malfunctions caused by water is out of warranty and repair may be refused. If the repair is available, it is acceptable for a fee because it is out of the warranty.
- Do not charge in the following places.
 - Extremely high or low temperature, or high humidity
 - Damp, dusty, or with excessive vibration
- Charging may stop to protect the battery or take more time in an area with high or low temperature. Avoid areas with high or low temperatures to restore the normal charging.
- The operating temperature of the sensors and charging case between 0°C (32°F) and 40°C (104°F). Do not use the device in locations that exceed the operating temperature.
- If charging a sensor while it is attached to the charging case, use a Sony AC adapter "Fast Charger XQZ-UC1".

Instructions to prevent reasonably foreseeable mishandling of the battery

This product has a built-in lithium-ion battery. Do not disassemble or alter the product. Do not expose this product, including the battery, to excessive heat, fire, etc., for an extended period of time. Do not subject this product, including the battery, to extreme low-temperature conditions that may result in overheating and thermal runaway. Disposing of the battery into fire or a hot oven or mechanically crushing or cutting the battery can result in an explosion. Leaving the battery in an extremely high-temperature surrounding environment can result in an explosion or the leakage of flammable liquid or gas. Subjecting the battery to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas. The battery must be charged before use. Always use the Sony-branded charger and USB cable. Refer to the manufacturer's instructions or equipment manual for proper charging instructions. After extended periods of storage, it may be necessary to charge and discharge the battery several times to obtain maximum performance.

DISPOSAL OF RECHARGEABLE BATTERIES

You can help preserve our environment by returning your used rechargeable batteries to the collection and recycling location nearest you.

For more information regarding recycling of rechargeable batteries, visit www.sony.com/ecotrade

Caution: Do not handle damaged or leaking rechargeable batteries.

Limited warranty

Subject to the conditions of this limited warranty, Sony or its relevant local affiliates warrants this device against defects in design, material and workmanship at the time of its original purchase by a consumer and for 1 year thereafter. Contact an authorized Sony service partner to get further information.

What we will do

If, during the warranty period, this device fails to operate under normal use and service, due to defects in materials or workmanship, authorized Sony distributors or service partners will, at their discretion, either repair or replace the device in accordance with the conditions stipulated herein.

Conditions

- The warranty is valid only if the original receipt issued to the original purchaser by the authorised dealer, specifying the date of purchase and serial number, is presented with the device to be repaired or replaced.
 - For customers in the United States**
Sony is not responsible for any labor or parts costs you incur relating to repairs or service from providers/ services other than from an authorised Sony service partner.
 - For customers in other countries and regions**
Tampering with any of the seals on the device will void the warranty.
- If Sony repairs or replaces the device, the repaired or replaced device shall be warranted for the remaining time of the original warranty period or for ninety days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of Sony.
- This warranty does not cover any damage, malfunctions and/or failures of the device due to normal wear and tear, or due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with instructions for use and maintenance of the device. Nor does this warranty cover any damage, malfunctions and/or failures of the device due to accident, modification or adjustment, acts of God or damage resulting from liquid outside of the approved levels.
- There are no express warranties, where written or oral, other than this limited warranty. All implied warranties, including without limitation the implied warranties of merchantability or fitness for a particular purpose, are limited to the duration of this limited warranty. In no event shall Sony or its vendors be liable for incidental or consequential damages of any nature whatsoever, including but not limited to lost profits or commercial loss, to the full extent those damages can be disclaimed by law. Some countries/regions do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Any change or modification not expressly approved by Sony may void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment has very low levels of RF energy that is deemed to comply without testing of specific absorption rate (SAR). To avoid damage to the device and injury to yourself, always wear the product as instructed in the manual and with the applicable straps/accessories.

For question regarding your product or for the Sony Service Center nearest you, call 1-800-222-7669 (SONY). Supplier's Declaration of Conformity Trade Name : SONY Model : QM-SS1C Responsible Party : Sony Electronics Inc. Address : 16535 Via Esprillo, San Diego, CA 92127 U.S.A. Telephone Number : 858-942-2230

For customers in the United States

Owner's record

The model and serial numbers are located on the sensors and charging case. Record the serial number in the space provided below. Refer to them whenever you call upon Sony Customer Support regarding this product.

Model No. _____

Serial No. _____

Other Information

In this manual, descriptions of services or applications offered by third parties may be included. You may need separate registrations to the provider or license agreement to use the above-mentioned services or applications. For the applications you accessed through third party websites, confirm the terms of use of the applicable website and the applied privacy policy beforehand. Sony does not guarantee third party websites and their services, availability of applications, or performance.

Trademarks

- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license. Other trademark and trade names belong to their respective owners.
- USB Type-C® is a trademark of USB Implementers Forum.
- Other product and company names mentioned herein may be the trademarks of their respective owners. In the main text, ™ and ® marks are not noted.